# BM-575/577

### **SERVICE MANUAL**



US Model BM-575/577 AEP Model BM-577

Photo: BM-577

#### **SPECIFICATIONS**

Tape

MICROCASSETTE (normal position type)

Recording system

BM-577: 4-track 2-channel monaural BM-375: 2-track 1-channel monaural

Approx. 2.8 cm (11/4 in.) dia.

Tape speed

2.4 cm/s (13/16 ips), 1.2 cm/s (13/12 ips)

Frequency response

BM-577: 250 to 4,000 Hz (at 2.4 cm/s)

BM-575: 300 to 3,500 Hz (at 2.4 cm/s)

Microphone jack (minijack) sensitivity 0.2 mV for low impedance microphone

Output

Earphone jack (minijack) for 8 - 300 ohms earphone Power output

150 mW (at 10 % harmonic distortion)

**Battery life** 

Continuous recording hours with the built-in microphone:

Approx. 9 hours (average) with alkaline batteries.

Approx. 2 hours with a rechargeable battery after charged for 5 hours. Power requirements

3V DC

• Two size AAA (R03) batteries (not supplied)

Sony BP-43 rechageable battery pack (not supplied)

DC IN 3 V jack accepts:

 Sony AC-E30HG AC power adaptor (not supplied) for use on 120 V AC, 60 Hz (US model) or 220—230 V AC, 50/60 Hz (AEP model)
• Sony DCC-E130L car battery cord (not supplied) for use on 12 V car

battery

Dimensions (w/h/d) (incl. projecting parts and controls)

Approx.  $60 \times 122 \times 23.4 \text{ mm (w/h/d)}$  $(2\frac{1}{3} \times 4\frac{1}{3} \times 1\frac{1}{3})$  in.)

Approx. 155 g (5.5 oz.)

Approx. 185 g (6.5 oz.) (incl. batteries and cassette)

Supplied accessory


Carrying case (1) (BM-577 only)

Design and specifications are subject to change without notice.

Model Name Using Similar Mechanism	BM-575	BM-540
	BM-577	BM-560
Tape Transport Mechanism Type	BM-575	MB-575-50
rape transport Mechanism Type	BM-577	MB-577-50

#### Use only standard Microcassettes with this unit.

Non-standard microcassettes cannot be used because their "L" dimension (see illustration) is different.



Use the AC-E30HG AC power adaptor (not supplied). Connect the adaptor to the DC IN 3V jack and to a wall outlet. Do not use any other AC power adaptor.

Polarity of the plug



#### NOTES ON CHIP COMPONENT REPLACEMENT

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.





### SECTION 1 GENERAL

This section is extracted from instruction manual.

#### **TABLE OF CONTENTS**

Secti	<u>Title</u>	<u>Page</u>
1.	GENERAL	
	Welcome!	2
	About This Manual	2
	Operation Flow Chart	2
	Dictating with the Built-in Microphone	3
	Listening to the Dictation	3
2.	DISASSEMBLY	
2-1.	Lid (Cassette) Assy	4
2-2.	Cabinet (Rear)	4
2-3.	Cabinet (Front) Assy	5
2-4.	Speaker/DC-JACK Board	5
2-5.	Main Board	6
2-6.	Mechanism Deck Block	6
2-7.	Flywheel Assy	7
2-8.	S Reel Table Assy	7
2-9.	Take-up Reel Table Assy	8
2-10.	FWD Arm Assy	8
3.	MECHANICAL ADJUSTMENTS	9
4.	ELECTRICAL ADJUSTMENTS	9
5.	DIAGRAMS	
5-1.	Schematic Diagram—Main Section (BM-575)— .	11
5-2.	Printed Wiring Boards	
	-Main Section (BM-575)	13
5-3.	Printed Wiring Boards	
	-Main Section (BM-577)	17
5-4.	Schematic Diagram—Main Section (BM-577)— .	19
6.	EXPLODED VIEWS	
6-1.	Cabinet Section	21
6-2.	Chassis Section	22
6-3.	Mechanism Deck Section (1)	23
6-4.	Mechanism Deck Section (2)	25
7.	ELECTRICAL PARTS LIST	27

#### Welcome!

Thank you for purchasing the Sony Microcassette  $^{\text{TM}}$  Dictator. Some features are:

- •Simple operation with a slide-type function lever.
- You can put electronic indexing marks on recording (BM-577 only).
- •Three BATT lamps (including the DICT/BATT lamp) indicate the battery condition step by step (BM-577 only).
- VOR (Voice Operated Recording) system that starts and stops recording automatically in response to the sound, to save tapes and batteries.
- Three-digit tape counter for indexing the tape contents.
- FAST PB (fast playback) function that lets you listen to the tape with high speed.
- LOCK switch prevents the unit from accidental operation.
- 3-way powering system: batteries, AC house current and car battery.
- Tape-end alarm sounds at the end of the tape.

#### **About This Manual**

The instructions in this manual are for 2 models. The BM-577 is the model used for illustration purposes. Any differences in operation are clearly indicated in the text, for example, "BM-577 only."

#### **Operation Flow Chart**

Insert the batteri	es.
♦	
Insert a cassette.	
₽	
Select the tape s	peed and microphone sensitivity.
Π	Set the TAPE COUNTER to 000.
	Make sure that the LOCK switch is set to the opposite direction of the arrow.
4	Set the VOR switch to ON, if necessary.
Start dictation w	ith the built-in microphone.
	Record the electronic index signal to provide easy access of transcription. (BM-577 only)  Use the FAST PB (fast playback) function to check the dictated material.
Stop dictating.	
♦	
Eject the cassette	
₹}	


Hand the cassette to your secretary or transcriber without


rewinding the tape.

# ▶ Operating the Unit

# Dictating with the Built-in Microphone

You can start and stop dictating simply by sliding the function





- Slide the EJECT lever to open the cassette compartment lid.
- Insert a cassette with the side to start dictating facing the lid. Set the TAPE SPEED selector to the desired tape speed.

Set to	2.4 cm**	1.2 cm	
Recording time*	60 minutes	120 minutes	the state of the state of the state of

\* Using both sides of the MC-60BM Microcassette.
\*\* For optimum sound (recommended for normal use), set to 2.4 cm.
Set the MIC SENS (microphone sensitivity) selector to the desired position.

Normal use Set to DICT (dictation) Recording a conterence or CONF (conterence
---

- Slide up the function lever to DICT (dictation).
- Speak into the microphone. The DICT/BATT lamp flashes depending on the strength of the
  - sound during recording.

    To stop dictating, slide down the function lever to STOP. To eject a cassette, slide the EJECT lever.

To economize the tapes and batteries
Set the VOR switch to ON. The tape moves only when sound is
picked up, and stops automatically when sound is no longer
detected (The DICT/BATT indicator goes out.), thus the minimum amount of tape is used.

# To index the tape contents Set the TAPE COUNTER to 000 by pushing the reset button before

To monitor the recording Connect an earphone to the EAR (earphone) jack. dictating.

# To listen to the just-recorded contents while dictating Slide down the function lever to B. SPACE (back space), and

release it at the desired point.

When a beep sounds and the DICT/BATT lamp goes out The tape reaches the end. Slide the function lever to STOP.

Use the BE-9H cassette eraser (not supplied). To erase the entire tape contents

# Putting Marks during Recording for Easy Access (BM-577 only

When your secretary uses the Sony transcriber equipped with auto-Press E-INDEX lightly when you have special instructions for your secretary about the material or mark the end of the letter. An electronic index signal will be recorded on the tape. This signal is the same as the LTR signal of the Sony transcriber. stop function, the tape automatically stops at each index signal when it is rewound or rapidly advanced. Your secretary will be able to search a necessary dictation easily.

The cue-maker function of some Sony microcassette-conder may not operate on the electronic indexing mark recorded with the BM-57, because the cuemaker function and the electronic indexing function have no effect each other.




# Dictating with an External Microphone or with **Telephone Recording Adaptor**

power of the microphone is supplied from this unit.

For telephone recording, connect the TL-4 telephone recording adaptor (not supplied) to the MIC jack. For details, refer to the TL-4. electret condenser microphone with "plug-in power" system, the Connect the microphone to the MIC jack. When connecting the nstruction manual.



# Listening to the Dictation



Make sure that the LOCK switch is set to the opposite direction of the arrow.

- Slide the EJECT lever to open the cassette compartment lid.
   Insert a cassette with the side to start listening facing the lid.
  - Set the TAPE SPEED selector to the same position as that in
- Slide down the function lever to LISTEN
- Adjust VOL (volume).
- 6 To stop playback, slide up the function lever to STOP.

Slide up the FAST PB (fast playback) switch while listening to the To listen to the tape at a faster speed than normal

# To rewind the tape

Slide down the function lever at the B. SPACE (back space) and release it at the desired point.

function lever set to STOP. To stop the tape, release the FF/CUE To rapidly advance the tape Slide the FF/CUE lever in the direction of the arrow, with the


To skip over unnecessary portions
During playback, slide the FF/CUE lever in the direction of the arrow. When you release the lever, the unit will automatically return to the playback mode.

For private listening Connect the earphone to the EAR jack and the sound does not come out through the speaker.

## SECTION 2 DISASSEMBLY


Note: Follow the disassembly procedure in the numerical order given.

#### 2-1. LID (CASSETTE) ASSY




#### 2-2. CABINET (REAR)


Note: On install, set to the knobs and switches.




#### 2-3. CABINET (FRONT) ASSY



#### 2-4. SPEAKER/DC-JACK BOARD




#### 2-5. MAIN BOARD




#### 2-6. MECHANISM DECK BLOCK


Note: On install, set to the knobs and lever of mechanism deck block.




#### 2-7. FLYWHEEL ASSY




#### 2-8. S REEL TABLE ASSY



#### 2-9. TAKE-UP REEL TABLE ASSY



#### 2-10. FWD ARM ASSY



### SECTION 3 MECHANICAL ADJUSTMENTS

#### **PRECAUTION**

- Clean the following parts with a denatured alcohol moistened swab:
  - record/playback head (BM-577) erase head (BM-577) record/playback/erase head (BM-575) pinch roller rubber belts capstan idlers
- 2. Demagnetize the record/playback/(erase) head with a head demagnetizer.
- 3. Do not use a magnetized screwdriver for the adjustments.
- 4. After the adjustments, apply suitable locking compound to the parts adjusted.
- 5. The adjustments should be performed with the rated power supply voltage (dc 2.5V) unless otherwise noted.
- Switches and control should be set as follows unless otherwise specified.

MIC SENS selector : CONF
TAPE SPEED selector : 2.4cm
FAST PB switch : OFF
VOR switch : OFF

VOL control : mechanical center

#### **Torque Measurement**


Mode	Torque meter (Cassette type)	Meter reading
LISTEN	CQ-103M	5-12g•cm (0.069-0.167 oz•inch)
FF/CUE	CQ-201M	more than 5g·cm (more than 0.069 oz·inch)
B. SPACE	CQ-201M	more than 14g·cm (more than 0.194 oz·inch)

#### **Tape Tension Measurement**

Mode	Tension meter (Cassette type)	Meter reading
LISTEN	CQ-403M	25-55g (0.88-1.94 oz)

#### **Timing Adjustment**

- Take-up reel spindle should rotate at the same time as pinch roller or earlier than pinch roller in STOP to LISTEN/DICT mode.
  - Confirm that the pinch roller presses to capstan and they rotate.
- 2. When they are not correctly rotate, adjust the place of adjustment plate so that it is wide.



### SECTION 4 ELECTRICAL ADJUSTMENTS

#### **PRECAUTION**

- 1. Demagnetize the record/playback/(erase) head with a head demagnetizer.
- 2. Do not use a magnetized screwdriver for the adjustments.
- 3. After the adjustments, apply suitable locking compound to the parts adjusted.
- 4. The adjustments should be performed with the rated power supply voltage (dc 2.5V) unless otherwise noted.
- 5. The adjustments should be performed in the order given in this service manual. (As a general rule, playback circuit adjustment should be completed before performing recording circuit adjustment.)
- Switches and control should be set as follows unless otherwise specified.

MIC SENS selector : CONF TAPE SPEED selector : 2.4cm FAST PB switch : OFF VOR switch : OFF

VOL control : mechanical center

#### **Test Tape**


Туре	Signal	Used for
WS-24	3kHz, -10dB	Tape Speed (2.4cm) Adjustment
WS-12	3kHz, -10dB	Tape Speed (1.2cm) Adjustment
S-2-A030	3kHz, -20dB	Head Azimuth Adjustment

#### Tape Speed (2.4cm) Adjustment

Setting:

TAPE SPEED selector: 2.4cm

#### Procedure:



2. Adjust RV102 so that the frequency counter reads 2,990 to 3,010Hz.


Adjustment Location: See page 10.

#### Tape Speed (1.2cm) Adjustment

Setting:

TAPE SPEED selector: 1.2cm


#### Procedure:



 Adjust RV103 so that the frequency counter reads 2,990 to 3,010Hz.


Adjustment Location: See page 10.

#### Adjustment Location:



### Record/playback Head Azimuth Adjustment Procedure:


1. Mode: LISTEN



2. Turn the adjustment screw for maximum VTVM reading.

Note: Several peaks may apper, but take the maximum.

#### **Adjustment Location:**




#### **Record Bias Adjustment**

#### Setting:


TAPE SPEED selector: 2.4cm

#### Procedure:

1. Mode: DICT (record)



2. Mode: LISTEN (playback)



- 3. LISTEN (playback) the signal recorded in step 1.
- 4. Turn the VOL control so that the VTVM reads within 0dB.


Confirm that the distortion meter reads within adjustment limits.

- 5. Set the TAPE SPEED selector to 1.2cm and repeat steps 1 to 4.
- 6. If the adjustment limits are not satisfied, soldering the tap as follows.


#### Adjustment limits:

tape speed	distortion
2.4cm/s	within 10%
1.2cm/s	within 14%


Soldering Point: main board (conductor side)



### SECTION 5 DIAGRAMS



#### 5-2. PRINTED WIRING BOARDS—MAIN SECTION (BM-575)—




#### Semiconductor Location


• Schilleonauctor		
Ref. No.	Location	
D101	G-10	1
D102	G-10	l
D103	G-7	
D104	H-5	l
D105	H-14	
IC101	G-8	
IC102	G-6	l
IC103	1-5	l
IC104	H-7	
Q101	G-9	
Q102	F-9	
Q103	H-11	Į
Q104	G-9	
Q105	H-9	
Q106	H-11	
Q107	F-7	
Q108	F-5	l
Q109	G-5	l
Q110	G-6	l
Q111	G-6	l
Q112	G-5	l
Q113	F-6	
Q114	H-6	
Q115	F-5	l
Q116	H-6	
Q117	G-6	
Q118	H-6	
Q119 Q120	H-6 H-7	
0121	H-9	
0122	H-9	
0123	H-9	
Q123 Q124	H-9	
		1

- parts extracted from the conductor side.
- : Through hole. : Pattern on the side which is seen. (The other layer's patterns are not indicated.)

Ref. No.	Location	
D1	G-3	
D101	G-10	
D102	G-10	
D103	G-7	
D104	G-5	
D105	H-14	
D106	H-14	
D107	G-14	
IC101	G-8	
IC102	G-6	
IC103	I-5	
IC104	H-7	
Q101	G-9	
Q102	F-9	
Q103	H-11	
Q104	G-9	
Q105	H-9	
Q106	H-11	
Q107	F-7	
Q108	F-5	
Q109	G-5	
Q110 Q111	G-6 G-6	
Q111	G-5	
0113	F-6	
Q114	H-6	
Q115	F-5	
0116	H-6	
Q117	G-6	
Q118	H-6	
Q119	H-6	
Q120	H-7	
Q121	H-9	
Q122	H-9	
Q123	H-9	
Q124	H-9	
Q125	1-7	
Q126	1-8	
Q127 Q128	H-8 H-7	

- i: parts extracted from the conductor side.
  i: Through hole.
  i: Pattern on the side which is seen.
  (The other layer's patterns are not indicated.)





### SECTION 6 EXPLODED VIEWS

#### NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked "\*" are not stocked since they are seldom required for routine service.
   Some delay should be anticipated when ordering these items.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Color Indication of Appearance Parts Example:


KNOB, BALANCE (WHITE)...(RED)

↑

Parts Color Cabinet's Color


 Hardware (# mark) list and accessories and packing materials are given in the last of this parts list.

#### 6-1. CABINET SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	A-3042-794-A	LID (CASSETTE) ASSY		9	3-927-395-01	SPRING, COMPRESSION	
2	3-578-232-21	ORNAMENT, ADJUSTMENT HOLE		10	3-926-697-01	CABINET (REAR) (BM-577)	
3	A-3042-786-A	CABINET (FRONT) ASSY (BM-575)		10	3-926-697-11	CABINET (REAR) (BM-575)	
3	A-3042-789-A	CABINET (FRONT) ASSY (BM-577)		11	3-927-405-01	KNOB (MIC SENS)	
4	3-672-586-01	SCREW (1.4), TAPPING		12	3-927-406-01	KNOB (FAST PB)	
<b>*</b> 5	1-657-826-11	DC-JACK BOARD		13	3-309-597-01	SCREW (1.4), TAPPING	
* 6	3-927-397-01	BRACKET, SP		14	3-947-677-01	SCREW (1.7X4), TAPPING (B)	
7	3-927-400-01	PLATE, BLIND		SP1	1-504-961-11	SPEAKER	
8	3-927-396-01	CUSHION, SP					


#### 6-2. CHASSIS SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	A-3042-793-A	LID ASSY, BATTERY CASE		63	3-927-401-01	LEVER, CHARGE SWITCH (BM-577)	
52	3-927-394-01	SHAFT (BATTERY CASE LID)		64		BUTTON (EJECT)	
53	3-927-398-01	KNOB (TAPE SPEED)		65	3-927-403-01	KNOB (FF/CUE)	
* 54	3-927-393-01	SPRING, BATTERY CASE LID	İ	* 66	A-3016-730-A	MAIN BOARD, COMPLETE (BM-575)	
* 55	1-657-825-11	LED BOARD		* 66	A-3016-735-A	MAIN BOARD, COMPLETE (BM-577)	
56	A-3042-788-A	CABINET (MIDDLE) ASSY (BM-575)		67	3-927-392-01	BUTTON (LOCK) (BM-575)	
56	A-3042-791-A	CABINET (MIDDLE) ASSY (BM-577)		68		SCREW (1.4), TAPPING	
57	3-927-413-01	SPRING, BATTERY	Ì	69		WASHER, COTTER POLYETHYLENE	
58	3-306-145-01	HOLDER (MICROPHONE)	[	70	3-701-437-01	WASHER	
59	A-3042-792-A	BUTTON ASSY, CONTROL		* 71		CUSHION, VIBRATION PREVENTION	
60	3-927-404-01	BUTTON (E-INDEX)		72	3-309-597-61	SCREW (1.4X6), TAPPING	
* 61 62		COVER, BATTERY SPRING, TENSION (BM-577)		MIC1		MICROPHONE, ELECTRET CONDENSES	₹


#### 6-3. MECHANISM DECK SECTION (1)

(MB-575-50: BM-575) (MB-577-50: BM-577)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	3-306-149-01	SPRING, TORSION		120	3-578-138-01	SHIM (t=0.1)	
102		SHAFT (HEAD FITTING)		120	3-578-138-11	SHIM (t=0.2)	
103	3-704-375-01	SCREW (1. 7X5. 5), (+P), PI	RECISION	121	3-315-384-11	WASHER, STOPPER	
104	3-570-558-00	SPRING, COMPRESSION		* 122	3-927-428-01	RETAINER (A), CASSETTE	
105	1-548-516-00	TIMER, TAPE		123		SCREW (1. 4X2. 5), (+P), F	PRECISION (BM-577)
106	3-306-164-01	SPACER (HEAD)		124	3-927-425-01	SPRING, TENSION	
* 107	3-302-476-00	CLAMP		* 125	3-924-116-01	LEVER, EJECT	
* 108	3-302-464-00	GUIDE, TAPE		* 126	3-924-115-01	LEVER, LOCK	
109	X-3302-409-0	PINCH LEVER ASSY		127	3-927-427-01	SPRING, TENSION	
110	3-302-459-00	CLAW (S), REEL		128	3-927-426-01	SPRING, TENSION	
111	3-302-460-00	CLAW (T), REEL		129	3-927-424-01	SPRING, TENSION	
112	3-701-436-01	WASHER, 1.6		130	3-928-722-01	PLATE, COUNTER	
113	3-578-255-11	RING (E1.5), RETAINING		* 131	3-927-441-01	LEVER, CASSETTE DETECTION	ON (BM-577)
* 114	3-302-474-00	BRACKET, ERASE HEAD (BM-	577)	132	3-927-442-01	SPRING, CASSETTE DETECT	ION (BM-577)
115	3-309-836-01	SHAFT, FITTING, MOTOR		HD1	1-500-271-11	HEAD, MAGNETIC (REC/PB/	ERASE) (BM-575)
116	3-570-770-00	CUSHION (A), MOTOR		HD1	1-543-725-11	HEAD, MAGNETIC (REC/PB)	(BM-577)
117		PANEL ASSY, SUB		HE1		ESF194-62G (ERASE HEAD)	
118		HOLDER ASSY, LID		M1	A-3042-785-A	· · · · · · · · · · · · · · · · · · ·	
* 119	X-3370-773-1	·					

6-4. MECHANISM DECK SECTION (2) (MB-575-50: BM-575) (MB-577-50: BM-577)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	3-311-815-11	WASHER, POLYETHYLENE		170	3-570-552-00	SPRING, TENSION	
152	X-3306-122-1	ARM ASSY, JOINT		171	3-704-374-01	SCREW (1.4X2.5), (+P), PRECIS	ION
153	X-3370-769-1	CHASSIS ASSY, MECHANICAL		* 172	3-306-186-01	SHAFT (PC BOARD GUIDE)	
* 154	3-302-461-00	RETAINER, SPRING		* 173	X-3306-123-1	CHASSIS ASSY, HEAD (BM-577)	
155	3-302-567-01	SPRING (STEEL BALL), COMPRESSION	ON	* 173	X-3370-771-1	CHASSIS ASSY, HEAD (BM-575)	
156	3-302-495-00	GUIDE, ARM, FWD		174	3-561-634-00	SPRING, TENSION	
157	X-3306-111-1	FLYWHEEL ASSY		* 175	3-302-541-00	BUSHING, FWD ARM	
* 158	3-306-197-01	GUIDE (B), CONTROL		176	3-527-188-00	SPRING, TENSION	
159	3-302-490-00	SPRING, BS RETURN		* 177	X-3370-770-1	BRACKET ASSY, FF	
160	3-302-536-00	GUIDE, CONTROL LEVER		* 178	3-302-462-00	RETAINER, H CHASSIS	
* 161	3-924-114-01	LEVER, CONTROL		179	3-927-429-01	PULLEY, RELAY	
162	3-561-645-00	BELT, C		180	3-927-430-01	REFLECTOR	
163	3-315-384-11	WASHER, STOPPER		181	3-704-245-51	SCREW (1. 4X3. 5)	
164	X-3302-412-0	ARM ASSY, FWD		182	3-704-246-31	SCREW (P1. 4X2. 5)	
165	3-927-420-01	SPRING, TENSION		183	3-927-421-01	SPRING, TENSION	
166	X-3302-424-1	TABLE ASSY, REEL, TAKE-UP		184	3-927-423-01	BELT	
167	3-701-436-01	WASHER, 1.6		* 185	3-924-113-01	SPRING, DICT	
168	X-3302-414-0	TABLE ASSY, REEL, S		186	3-927-422-01	BELT	
* 169	3-302-559-00	ROLLER, GUIDE, H PC BOARD		* 187	X-3370-772-1	ARM ASSY, DICT	

# SECTION 7 ELECTRICAL PARTS LIST

DC-JACK

LED

MAIN

(BM-577)

#### NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
   All resistors are in ohms.
   METAL:Metal-film resistor.
   METAL OXIDE: Metal oxide-film resistor.
   F:nonflammable
- Items marked "\*" are not stocked since they are seldom required for routine service.
   Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS

In each case,  $u:\mu$ , for example:  $uA \dots \mu A \dots uPA \dots \mu PA$ .

uPB. : μPB. uPC. : μPC. : μPD. : μPD.

• CAPACITORS
uF: µF

• COILS uH: μH When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description		Remark
*	1-657-826-11	DC-JACK BOARD		*			OMPLETE (BM-575 OMPLETE (BM-577	
		< CAPACITOR >						
C1	1-164-156-11	CERAMIC CHIP 0. 1uF	25V			< CAPACITOR >		
		< DIODE >		C101	1-164-156-11	CERAMIC CHIP	0. 1uF	25V (BM-575)
D1	0_710_020_75			C101	1-165-176-11	CERAMIC CHIP	0. 047uF	16V
DΙ	0-118-830-13	DIODE SB05-05CP (BM-577)		C102	1-107-826-11	CERAMIC CHIP	0. 1uF	(BM-577) LO% 16V
		< JACK >		C102	1_165_176_11	CERAMIC CHIP	0.047	(BM-577)
J1	1-764-628-11	JACK, DC (POLARITY UNIFIED					0. 047uF	16V (BM-575)
******	*******	***********	(DC IN 3V)	C103	1-104-908-11	TANTAL. CHIP	47uF	20% 4V
•				C104	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
*	1-657-825-11			C105	1-162-968-11		0. 0047uF	.0% 50V
		*****		C106	1-107-826-11	CERAMIC CHIP	0. 1uF	.0% 16V (BM-577)
		< DIODE >		C106	1-165-176-11	CERAMIC CHIP	0. 047uF	.0% 16V
D105 D105	8-719-047-19 8-719-047-19	, , . , ,		C107	1-162-968-11	CERAMIC CHIP	0. 0047uF 1	(BM-575) .0% 50V
D106	8-719-047-19	, , , , , , , , , , , , , , , , , , , ,	,	C108	1-162-970-11	CERAMIC CHIP	0. 01uF 1	.0% 25V
D107	8-719-047-19		, , , , , , , , , , , , , , , , , , ,	C109	1-107-826-11			0% 16V
								(BM-575)
		< RESISTOR >		C109	1-165-176-11	CERAMIC CHIP	0. 047uF 1	0% 16V (BM-577)
R156	1-216-833-11	METAL CHIP 10K 5%	1/16W	C110	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
R601	1-216-822-11	METAL CHIP 1.2K 5%	1/16W (BM-577)	C111	1-126-781-11			0% 4V
R602	1-216-815-11	METAL CHIP 330 5%	1/16W	C112	1-164-156-11	CERAMIC CHIP	0. 1uF	25V .
			(BM-577)				0. 14.	(BM-577)
R603	1-216-818-11	METAL CHIP 560 5%	1/16W	C112	1-164-677-11	CERAMIC CHIP	0. 033uF 1	0% 16V
			(BM~577)					(BM-575)
R604	1-216-814-11	METAL CHIP 270 5%	1/16W	C113	1-162-964-11			0% 50V
			(BM~577)	C114	1-164-156-11		0. 1uF	25V
		< SWITCH >		C115	1-104-847-11	TANTAL. CHIP	22uF 2	0% 4V
				C116	1-164-346-11	CERAMIC CHIP	1uF	16V
S11		SWITCH, LEAF (CASSETTE IN)		C117	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
******	******	***********	******	C118	1-162-964-11			0% 50V
				C119	1-104-700-11			0% 16V
				C120	1-162-966-11	CERAMIC CHIP	0. 0022uF 1	0% 50V

## MAIN

Ref. No.	Part No.	Description		I	Remark	Ref. No.	Part No.	Description		Remark
C120	1-162-967-11	CERAMIC CHIP	0. 0033uF	10%	50V	<u> </u>		< DIODE >		
24.04	4 404 040 44	OPPANIA AUTO	4.5		(BM-575)	<b>N</b> 404	0.540.044.00	D. 2000		
C121		CERAMIC CHIP	1uF	0.00/	16V	D101	8-719-941-23			
C122		TANTALUM CHIP	10uF	20%	4V	D102	8-719-941-23			
C123	1-126-781-11		220uF	20%	4V	D103	8-719-948-98		T-148	
C124	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V	D104	8-719-801-78	DIODE 1SS18	14	
C125		CERAMIC CHIP	0. 047uF	10%	16V			< IC >		
C126		CERAMIC CHIP	0. 1uF		25V					
C127	1-162-966-11	CERAMIC CHIP	0. 0022uF	10%	50V		8-759-701-02			
C128	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	IC102	8-759-701-51	IC NJM2072N	i	
C129	1-104-847-11	TANTAL. CHIP	22uF	20%	4V		8-759-804-43 8-759-701-51		Ī	,
C130	1-162-927-11	CERAMIC CHIP	100PF	5%	50V					
C131	1-126-779-91		47uF	20%	4V			< JACK >		
C132		TANTALUM CHIP	3. 3uF	20%	6. 3V			Conon >		
C133		TANTAL. CHIP	1uF	20%	16V	J2	1-766-156-11	IACK (EAD)		
C134		CERAMIC CHIP	0. 001uF	10%	50V	J3	1-766-156-11	, ,		
6134	1-102-904-11	CERAMIC CHIP	0. 001ur	10%	5UV	13	1-100-130-11	JACK (MIC)		
C135		CERAMIC CHIP	0.001uF	10%	50V			< JUMPER RESI	STOR >	
C136		CERAMIC CHIP	0. 0012uF	10%	<b>I</b>					
C137		CERAMIC CHIP	0. 0018uF	10%		JP101	1-216-296-00	METAL CHIP	0 5%	1/8W (BM-575)
C138	1~104-932-11	CERAMIC CHIP	10uF		16V					
					(BM-577)			< PHOTO REFLE	CTOR >	
C138	1-135-201-11	TANTALUM CHIP	10uF	20%	4V					
					(BM-575)	PH101	8-749-011-74	PHOTO REFLECT	OR SPI-335-	74BC
C139	1-162-964-11	CERAMIC CHIP	0. 001uF	10%	50V			< TRANSISTOR	>	
C140	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V					
C141	1~164-346-11	CERAMIC CHIP	1uF		16V	Q101	8-729-117-32	TRANSISTOR	2SC4177	
C142	1-164-346-11	CERAMIC CHIP	1uF		16V	Q102	8-729-117-32	TRANSISTOR	2SC4177	
C143	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V	Q103	8-729-800-37	TRANSISTOR	2SD1048-X7	
	.,	•				Q104	8-729-117-32	TRANSISTOR	2SC4177	
C144	1-164-156-11	CERAMIC CHIP	0. 1uF		25V	Q105	8-729-805-91		2SA1563	
C145		CERAMIC CHIP	0. 0047uF	10%	,	4				
C146		TANTAL. CHIP	22uF	20%		Q106	8-729-800-37	TRANSISTOR	2SD1048-X7	
C147		TANTAL. CHIP	47uF	20%	4V	Q107	8-729-805-94		2SC4047	
C148		CERAMIC CHIP	0. 0012uF	10%	50V	Q108	8-729-805-94		2SC4047	
0140	1 104 730 11	OLIMINIO OIII	0. 0012di	10/0	304	Q100 Q109	8-729-807-87			
C149	1_162_067_11	CERAMIC CHIP	0. 0033uF	10%	50V	Q109 Q110	8-729-117-32		2SB1295-UL6	
C150					i	· ATIO	0-129-111-32	TRANSISION	2SC4177	
0130	1-104-047-11	TANTAL. CHIP	22uF	20%	4V	0111	0 700 005 01	TDANCICTOD	2011502	
01.51	1 107 000 11	GEDANIG GUID	0.4	4.00/	(BM-577)	Q111			2SA1563	
C151	1-107-826-11	CERAMIC CHIP	0. 1uF	10%	,	Q112	8-729-807-87		2SB1295-UL6	
					(BM-577)	Q113	8-729-805-94		2SC4047	
C152	1-107-826-11	CERAMIC CHIP	0. 1uF	10%		Q114	8-729-901-06		DTA144EK	
					(BM-577)	Q115	8-729-805-94	TRANSISTOR	2SC4047	
C153	1-135-201-11	TANTALUM CHIP	10uF	20%	4V					
					(BM-577)	Q116	8-729-901-06	TRANSISTOR	DTA144EK	
						Q117	8-729-117-32	TRANSISTOR	2SC4177	•
C154	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	Q118	8-729-117-32	TRANSISTOR	2SC4177	
C155	1-164-677-11	CERAMIC CHIP	0. 033uF	10%	16V	Q119	8-729-117-32	TRANSISTOR	2SC4177	
C156	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	Q120	8-729-805-91	TRANSISTOR	2SA1563	
C157		TANTAL. CHIP	47uF	20%	4V	•				
C158		TANTALUM CHIP	10uF	20%	4V	Q121	8-729-805-91	TRANSISTOR	2SA1563	
	201 11			204	(BM-575)	Q122	8-729-117-32		2SC4177	
					(Din 010)	Q123	8-729-216-22		2SA1162-G	
C159	1-164-346-11	CERAMIC CHIP	1uF		16V	Q123	8-729-210-22		2SC4177	
0103	1 104 040 11	OPIGRAIO OIIII	Iui		101					77\
						Q125	8-729-117-32	TRANSTSTUK	2SC4177 (BM-5	(1)

#### MAIN

Ref. No.	Part No.	Description			Remark		Ref. No.	Part No.	Description			Remark
Q126	8-729-117-32		2SC4177	(BM-	577)		R137	1-218-269-11	METAL GLAZE	360	5%	1/16W
Q127	8-729-805-91	TRANSISTOR	2SA1563	(BM-	577)	-	R138	1-216-822-11		1. 2K		1/16W
Q128	8-729-117-32	TRANSISTOR	2SC4177				R139	1-216-837-11		22K	5%	1/16W
							R140	1-216-061-00		3. 3K		1/10W
		< RESISTOR >					R141	1-216-823-11		1. 5K		1/16W
										2. 011		1/1011
R101	1-216-820-11		820	5%	1/16W		R142	1-216-823-11		1. 5K	5%	1/16W
R102	1-216-829-11		4. 7K		1/16W		R143	1-216-818-11	METAL CHIP	560	5%	1/16W
R103	1-216-835-11		15K	5%	1/16W		R144	1-216-853-11	METAL CHIP	470K	5%	1/16W
R104	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W		R145	1-216-852-11		390K	5%	1/16W
R104	1 210 000 11	METAL CHID	0.017	For	(BM-577)		R146	1-216-845-11	METAL CHIP	100K	5%	1/16W
R104	1-216-828-11	METAL CHIP	3. 9K	5%	1/16W					t		
					(BM-575)		R147	1-216-833-11		10K	5%	1/16W
DIOE	1 010 004 11	METAL OHID	4 01/	F0/	4 /4 000		R148	1-216-841-11		47K	5%	1/16W
R105 R106	1-216-824-11		1. 8K		1/16W		R149	1-216-821-11		1K	5%	1/16W
	1-216-841-11		47K	5%	1/16W		R150	1-216-809-11		100	5%	1/16W
R107	1-216-841-11		47K	5%	1/16W		R151	1-216-843-11	METAL CHIP	68K	5%	1/16W
R108	1-216-817-11		470	5%	1/16W	1						
R109	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W	1	R152	1-216-817-11		470	5%	1/16W
D440	1 010 007 44	Man and					R153	1-216-829-11		4. 7K	5%	1/16W
R110	1-216-827-11		3. 3K		1/16W	}	R154	1-216-857-11		1M	5%	1/16W
R111	1-216-823-11		1. 5K		1/16W	Ì	R155	1-216-817-11		470	5%	1/16W
R112	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W		R157	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W
R112	1-216-825-11	METAL CHIP	2. 2K	5%	(BM-575) 1/16W		R158	1-216-811-11	METAL CHIP	150	5%	1/16W
R113	1-216-841-11	METAL CHIP	47K	5%	(BM-577) 1/16W		R158	1-216-815-11	METAL CHIP	330	5%	(BM-575) 1/16W
R114	1-216-833-11		10K	5%	1/16W		R159	1-216-811-11	METAL CHIP	150	5%	(BM-577) 1/16₩
R115	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W		D4.50					(BM-575)
R115	1-216-833-11	METAL CHIP	10K	5%	(BM-577) 1/16W		R159	1-216-814-11		270	5%	1/16W (BM-577)
R116	1_216_041_11	METAL CUID	4717	Γeν	(BM-575)		R160	1-216-835-11	METAL CHIP	15K	5%	1/16W
R117	1-216-841-11   1-216-813-11		47K	5% 5%	1/16W		5464					
11117	1 210 013-11	METAL CHIP	220	5%	1/16W		R161	1-216-843-11	METAL CHIP	68K	5%	1/16₩ (BM-577)
R118	1-216-821-11		1K	5%	1/16W		R162	1-216-847-11	METAL CHIP	150K	5%	1/16W
R119	1-216-809-11		100	5%	1/16W							(BM-577)
R120	1-216-820-11	METAL CHIP	820	5%	1/16W		R163	1-216-853-11	METAL CHIP	470K	5%	1/16W
R121	1-216-814-11	METAL CHIP	270	5%	1/16W		R164	1-216-845-11	METAL CHIP	100K	5%	1/16W
R122	1-216-812-11	METAL CHIP	180	5%	1/16W							(BM-577)
R123	1-216-852-11	METAL CUID	2001	Fω	4 /4 010		R165	1-216-853-11	METAL CHIP	470K	5%	1/16W
R124	1-216-793-11		390K 4. 7		1/16W							(BM-577)
R125	1-216-801-11			5% 5%	1/16W		D4.00	4 040 050 44 1	mm.i. a.r.			
R126	1-216-833-11 M			5% 5%	1/16W 1/16W		R166	1-216-852-11	METAL CHIP	390K	5%	1/16W
R127	1-216-833-11 M			5%	1/16W		D1 C7	1 010 000 11 1	TETAL CUAD	4 577	Ea.	(BM-577)
	1 21,0 000 11 11	ICIAL OIII	IUN	JA	1/10#		R167	1-216-823-11	METAL CHIP	1. 5K	5%	·1/16W (BM-577)
R128	1-216-831-11 N	METAL CHIP	6. 8K	5%	1/16W		R168	1-216-818-11 M	METAL CHIP	560	5%	1/16W
	1-216-833-11 M			5%	1/16W		11100	. 210 010 11 1	ETAL VIII	300	J/0	(BM-577)
	1-216-835-11 M			5%	1/16W		R169	1-216-809-11 M	METAL CHIP	100	5%	1/16W
R131	1-216-833-11 M	METAL CHIP		5%	1/16W			1 210 000 11 8	EINE OIIII	100	J /0	(BM-577)
R132	1-216-817-11 M	METAL CHIP		5%	1/16W		R170	1-216-154-00 N	IETAL GLAZE	15	5%	1/8W
R133	1-216-841-11 M	ETAL CHIP	47K	5%	1/16W							(BM-577)
	1-216-820-11 M			5%	1/16W		D171	1_916_154 00 9	ETAL CLASE	15	ΓO	4 /OW
	1-216-805-11 M			5%	1/16W		R171	1-216-154-00 M	ETAL GLAZE	15	5%	1/8W
	1-216-841-11 M			5%	1/16W		R172	1-216-813-11 M	ETAL CHIP	220	5%	(BM-577) 1/16W
												-, -, -, -, -, -, -, -, -, -, -, -, -, -

#### MAIN

Ref. No.	Part No.	Description			Remark
R173	1-216-807-11	METAL CHIP	68	5%	1/16\\(\mathbb{W}\) (BM-575)
R174	1-216-837-11	METAL CHIP	22K	5%	1/16W (BM-575)
R175	1-216-814-11	METAL CHIP	270	5%	1/16W (BM-575)
R175	1-216-822-11	METAL CHIP	1. 2K	5%	1/16W (BM-577)
R176	1-216-200-11	METAL GLAZE	1. 2K	5%	1/8W
R177	1-216-841-11	METAL CHIP	47K	5%	1/16W
		< SWITCH >			
S1	1 700 400 11	CMITCH CLIDE /	DEC (DD)		
		SWITCH, SLIDE (I			
S2		SWITCH, SLIDE ()		•	
S3		SWITCH, SLIDE (			
S4	1-572-922-11	. ,		3)	
S5	1-571-275-31	SWITCH, SLIDE (V	/OR)		
S6	1-572-288-11	SWITCH, PUSH (FI	CUE)		
S7		SWITCH, LEAF (PO			
S8		SWITCH, PUSH (BA		CHARGE	F) (RM-577)
S9		SWITCH, PUSH (B.			2) (Dil 011)
S10		SWITCH, TACTILE			OM 577\
510	1 032 000 11		(E-1M	JEA) (I	om=377)
		< TRANSFORMER >			
T101	1-433-286-11	TRANSFORMER, BIA	AS OSC	(LLATI	DN
		< THERMISTOR (POS	SITIVE)	>	
THP101	1-808-956-11	THERMISTOR, POST	TIVE		
		< VARIABLE RESIS	STOR >		
VR101	1-223-749-11	RES, VAR, CARBO	10K/	OK (VO	OL.)
		RES, ADJ, CERMET		1. 7K	/
		RES, ADJ, CERME		2. 2K	
		******			*****
		MISCELLANEOUS			A STATE OF THE STA
				•	A
105	1-548-516-00	TIMER, TAPE			A
HD1		HEAD, MAGNETIC	(REC/PI	3/EBASE	E) (BM-575)
HD1		HEAD, MAGNETIC			
110 1	- 010 120 11	ייייייי וייייייייייייייייייייייייייייי	(111/11)	, (Ditt	911/

8-825-772-01 ESF194-62G (ERASE HEAD) (BM-577)

MIC1 1-542-197-11 MICROPHONE, ELECTRET CONDENSER

A-3042-785-A MOTOR ASSY

1-504-961-11 SPEAKER

Ref. No.	Part No.	Description	Remark
	****	******	
	HAF	DWARE LIST	
	****	******	
#1	7-624-101-04	STOP RING 1.2 (E TYPE)	
#2		SCREW, PRECISION +K 1.4X1.6	
#3	7-627-451-08	SCREW, PRECISION +K 1.4X1.6	
#4	7-627-551-17	SCREW, PRECISION +P 1.4X2	
#5	7-627-551-27	SCREW, PRECISION +P 1.4X2.5	
#6	7-627-551-47	SCREW, PRECISION +P 1.4X1.4	
#7	7-627-850-07	SCREW, PRECISION +P 1.4X2	
` #8	7-627-850-08	SCREW, PRECISION +P 1.4X2	
#9	7-627-850-17	SCREW, PRECISION +P 1.4X2.5	
#10	7-627-850-47	SCREW, PRECISION +P 1.4X1.6	
#11	7-627-850-97	SCREW, PRECISION +P 1.4X2.2	
#12	7-671-111-11	BALL, STEEL 1.5MM	
#13	7-671-155-01	BALL, STEEL 3MM	
*****	*****	*********	*****

#### ACCESSORIES & PACKING MATERIALS

3-800-079-11 MANUAL, INSTRUCTION (ENGLISH, FRENCH) (AEP)

3-800-079-21 MANUAL, INSTRUCTION (ENGLISH) (US)

3-800-079-41 MANUAL, INSTRUCTION (GERMAN, DUTCH) (AEP)

3-927-586-01 CASE, CARRYING (BM-577)

3-927-765-01 INDIVIDUAL CARTON (BM-575)

3-927-767-01 INDIVIDUAL CARTON (BM-577)

Sony Corporation
Consumer A & V Products Company
Personal A & V Products Div.

-30-

HE1

SP1

# BM-575/577

# SONY. SERVICE MANUAL

US Model AEP Model

### **SUPPLEMENT-1**

File this supplement with the service manual.

Subject: Addition of the BM-575 AEP model.

The AEP model is identical with the US model except for the following parts.

DIFFERENT PARTS LIST

#### **ACCESSORIES & PACKING MATERIALS**

BM-575 US Model		BM-575 AEP Model
Part No. Description	Part No.	Description
	Part No. Description  3-800-079-11 MANUAL, INSTRUCTION (ENGLISH, FRENCE)  N (ENGLISH) (US)  3-800-079-41 MANUAL, INSTRUCTION	MANUAL, INSTRUCTION (ENGLISH, FRENCH) (AEP)
3-800-079-21 MANUAL, INSTRUCTION (ENGLISH) (US)		
	3-800-079-41	MANUAL, INSTRUCTION (GERMAN, DUTCH) (AEP)

Sony Corporation

# BM-575/577

# SONY. SERVICE MANUAL

US Model
BM-575/577
AEP Model
BM-577

### **CORRECTION-1**

Correct your service manual as shown below.

#### : indicates corrected portion.

Page		INCORRECT				CORRECT CORRECT					
22	Ref. No. 67	Part No. 3-927-392-01	Description BUTTON (LOCK) (BM-575)	Remark	Part No. 3-927-392-01	Description BUTTON (LOCK)	Re	emark			